



Software Release Notes

Software name: EasyGrid, EasyGrid-LT & EasyTest-II, Firmware

Software number/version: SOFT-00177 / R5.1.0.0

File size: 346KB (355278 bytes)

Release date: 2022/04/15

Download link1: <https://fiso.com/en/support/> (select folder EasyGrid V3.0)

Download link2: <https://fiso.com/en/support/> (select folder EasyGrid LT)

Download link3: <https://fiso.com/en/support/> (select folder EasyTest II)

Applicable to:

- EasyGrid, EasyGrid-LT & EasyTest-II, with Firmware SOFT-0177 R5.0.0.0 to R5.0.9.0.

Changes:

- The selection of the communication protocol (Nortech, Modbus or Ethernet) is now made with the EasyGrid Dip Switch #2.
- EasyGrid & EasyGrid-LT Ethernet configuration improvement (automatically set the required Modbus parameters to have good Ethernet communication).
- Minimum temperature is now -75°C instead of -60°C.
- The analog output factory default temperature range is now 4mA=-40°C and 20mA=225°C.

Fixed Issues:

- Intermittent power up issue with the initialization of the EasyGrid System Relay.

Note:

- The EasyGrid uHTML (GUI Firmware) SOFT-00252, should be updated to R3.1.0.0 after you have updated to SOFT-0177 R5.1.0.0.